

## Poly Maintenance & Care

Clean your poly furniture regularly with a non-abrasive soap and water to ensure the continued beauty of your furniture. While most of Leisure Lawns colors will only need to be cleaned a few times a year, colors like white, gray or ivory and other of our lighter colors will need to be cleaned more frequently to maintain their original beauty. With our lighter colors, spray the furniture with a non-abrasive cleaner then wipe the furniture with a cloth and rinse off with warm, clean water. We would not recommend using a pressure washer. But if you choose to use one, do not hold the pressure washer too close to the furniture. It may cause the material to tear away so be sure to hold the top more than 12" away from the furniture.

Do not place items on the furniture that will leave a stain. Do not place hot items directly on the furniture. If properly cared for, you will be able to enjoy your poly furniture for many years!

## Wood Maintenance & Care

Poly Lumber is manufactured to be resistant to corrosive substances, oils and fuels, insects, fungi, salt spray and other environmental stress. To maintain the original finish, clean the poly with soap and water. No sealing or painting is required; as a general rule, paint will not adhere to poly.